





# **Measurements of ion species separation using Thomson scattering**

**Presentation to  
Kinetic Physics Workshop**

**James Steven Ross**


# Summary

- Thomson scattering provides a local, time resolved measurement of plasma conditions (Te, Ne, flow)
- It can also be used to characterize ion species fractions for certain plasma regimes (small fraction of high-Z material in a low-Z plasma)
- The ion species fraction was measured for a CH laser ablated plasma
- The plasma is observed to be hydrogen rich at early times



# We create a high velocity plasma flow by irradiating a CH<sub>2</sub> foil target with 10 beams from the Omega Laser



Heater beams are on for 1 ns and deliver 5 kJ to target



# We create a high velocity plasma flow by irradiating a CH<sub>2</sub> foil target with 10 beams from the Omega Laser

The plasma expands at high speed ( $> 10^7$  cm/s)



## Timing



# We create a high velocity plasma flow by irradiating a CH<sub>2</sub> foil target with 10 beams from the Omega Laser


2 $\omega$  Thomson Scattering data provides  
 $n_e$ ,  $T_e$ ,  $T_i$ ,  $v$  measurements

## Timing





# Collective Thomson scattering from ion-acoustic and electron-plasma waves is used to measure the plasma conditions

Thomson scattering is the scattering of an electromagnetic wave by free electrons.





$$S(k, \omega) = \frac{2\pi}{k} \left| 1 - \frac{\chi_e}{\varepsilon} \right|^2 f_e \left( \frac{\omega}{k} \right) + \frac{2\pi Z}{k} \left| \frac{\chi_e}{\varepsilon} \right|^2 f_i \left( \frac{\omega}{k} \right)$$





Single foil evolution is consistent with adiabatic expansion  
with velocities between  $15 - 5 \times 10^7$  cm/s and  $n_e \sim 4 \times 10^{18}$  cm $^{-3}$

The wavelength shift from the incident wavelength ( $\lambda_0$ ) is a measure of the flow velocity






The wavelength shift between the peaks is a measure of the electron density






# Scattering from the electron feature is used to measure the electron temperature and density








# Scattering from the ion feature is used to measure the ion temperature, plasma flow velocity and species fraction





These measurements are only possible because  $n_e$  and  $T_e$  are constrained by the electron feature.

# An increased Hydrogen percentage is measured in the Thomson scattering volume at early times

The ion feature can be used to measure the ion species fraction and ion temperature





The electron temperature and density are measured using the electron feature



## Summary and future work

- Thomson scattering provides a local, time resolved measurement of plasma conditions (Te, Ne, flow)
- It can also be used to characterize ion species fractions for certain plasma regimes (small fraction of high-Z material in a low-Z plasma)
- The ion species fraction was measured for a CH laser ablated plasma
- The plasma is observed to be hydrogen rich at early times
- This technique can also be used to characterize interpenetrating flows which will be discussed by S. Le Pape in the next talk



NIF



