

A large blue parallelogram shape on the left side of the slide, containing the Northrop Grumman logo.

THE VALUE OF PERFORMANCE.
NORTHROP GRUMMAN

DPSS Amplifiers for High Energy, High Repetition Rate Applications

HEC-DPSSL

September 11-14, 2012

G. Jay Doster Ph.D.


Overview



-
- Architecture
 - Diode Laser Pumps
 - Energetics
 - Uniformity
 - Laser Materials
 - Performance
 - Pulse Trains
 - What's next?


Quasi-CW Gain Modules

- All modules are diode pumped solid state.
- Incorporate long life diode packages.
- Modules are available with rod sizes from 2mm to 25mm in diameter, 3cm to 12cm long, bar counts from 3 to 360, and pump energies up to 40 Joules.
- Modules use common parts to reduce costs and manufacturing times.




Gain Module Architecture

- The laser crystal is cooled by passing water over the rod at high Reynolds number.
- Five (or seven) around array design gives more uniform pump light distribution.
- Pump chamber includes a high reflector to increase the optical to optical coupling and increases the uniformity of the pump distribution.
- Design allows easily changing pump lengths and rod sizes.
- Coolant interface to module is easily modified to accommodate plumbing configuration of choice.




Diode Pump Life Time

- Diode are life tested under full operating conditions.
- 13 billion shot life times indicate 10,000 hour operation at 370 Hz.




Gain Module Amplifier Performance




- Stored energy inferred from small signal gain measurements.
- 31% optical to optical coupling over entire product range.

REA Modules Output Energy




REA Modules Output Energy



Gain Uniformity


- Gain uniformity is an important performance parameter.
- Results in less beam distortion, more usable aperture area, and higher system efficiency.




Different Gain Materials: Nd:YLF, Yb:YAG

- Quasi-CW pump YLF gain modules are also available.
 - Higher saturation fluence, longer lifetime means higher energy storage.
 - Lower fracture limit vs. YAG reduces average power.
- Rod sizes up to 18mm.
- Uses same technology and parts as a standard Nd:YAG module.
- Long pulse energies over 1 Joule at 5Hz have been demonstrated.
 - 6.35 mm rod, 60 mm pumped length, 30 bars, 3 Joules pump energy.
 - 8 mm rod, 60 mm pumped length, 90 bars, 6.3 J pump, 3.5 J output energy.
 - 10mm rod, 60mm pumped length, 120 bars, 6.7J pump, 3.5 J stored energy.
- Yb Materials:
 - High pump thresholds
 - High Density stacks
 - Un-pumped region losses
 - Ceramic materials with undoped rod ends.

Typical Thermal Lens Strength Performance




Small Signal Gain Performance





- Small signal gain is maintained as average power increases.

Beam Preservation



- Single head, single pass
 - Left is at 50Hz, right is at 100Hz.
- Degradation is due to thermally induced stress birefringence.

Use Compensation Scheme




- By using two heads with a polarization rotator in between, much lower polarization losses can be obtained.
- Typically losses are reduced to 1-2%.

Pulse Trains


- What are pulse trains?
 - A series a short pulse width, closely spaced pulses, occurring in a series of bursts.
 - Pulse width 100ns or shorter.
 - Repetition rates of 5kHz or more.
 - Bursts of 100Hz or less.
 - The burst of pulses is called a 'macro-pulse'.

- These are not hard limits, but guidelines.
 - Engineering trades to accommodate 'unusual' situations.




Examples of Modeling Output

- Input
- The
- The




Application – Image Amplification

- Generation of 2D bar codes with a single pulse.
- Input image is generated by a 2D mirror array (DLP).
 - Mirror array has low damage threshold.
 - Input energy fluence $< 1 \text{ mJ/cm}^2$.
 - Too low to mark materials of interest
- One REA single pass results in $\sim 140\text{x}$ amplification and good image quality.




Images

- Before amplification on left, after amplification (120x) on right.
- Resultant 2D bar code meets industry standards for contrast, resolution, etc.



What is possible?



Conclusions

- NGCEO has a selection of 1J+ COTS amplifiers utilizing long life laser diodes.
- Repetition rates of 100Hz are easily obtainable.
- Very uniform spatial profile increases system performance.
- These amplifiers are building blocks, or engines, that pump OPCPAs for driving high energy laser systems.

THE VALUE OF PERFORMANCE.

NORTHROP GRUMMAN

