

Investigation of spectroscopic properties and laser oscillation of oxides ceramics manufactured with SHS-MS method

*V.V. Zelenogorsky¹, S.S. Balabanov², Yu.V. Bykov¹,
S.V. Egorov¹, A.G. Ereemeev¹, E.M. Gavrishchuk², I.B. Mukhin¹,
O.V. Palashov¹, E.A. Perevezentsev¹, D.A. Permin²*

*¹Institute of Applied Physics, Russian Academy of Sciences,
Nizhny Novgorod, Russia*

*²Institute of Chemistry of High-Purity Substances, Russian
Academy of Sciences, Nizhny Novgorod, Russia*



Introduction

Nizhny Novgorod:

- *Institute of Chemistry of High-Purity Substances* stands for preparation of nano-powders
- *Institute of Applied Physics* stands for baking and samples benchmarking



**8th Laser Ceramics Symposium:
International Symposium on Transparent Ceramics
for Photonic Applications**

Nizhny Novgorod, Russia, 4.12.12 - 7.12.12

www.8lcs.iapras.ru






Y_2O_3 SHS technique from acetate nitrates complexes

Self-propagating high-temperature synthesis (SHS) means the synthesis of compounds (or materials) in a wave of chemical reaction (combustion) that propagates over starting reactive mixture owing to layer-by-layer heat transfer

Metal acetate nitrates were prepared by dissolving oxides in an aqueous solution of acetic and nitric acids:



SHS precursor



Reaction propagation



High-disperse oxide



Gyrotron-based system for materials processing

Utilization of microwave heating is promising due to absence of resistive heating elements which can contaminate material at high temperatures. The additional advantage of this method is its less energy consumption compared to conventional sintering




Impurity composition of powders was investigated using atomic emission spectrometry with inductively coupled plasma (AES-ICP) iCAP 6300 (USA) and revealed no significant differences in impurity composition of both starting powders (see table 2) and sintered ceramics.

6 kW 24 GHz gyrotron system

Ceramics


Scanning electron microscopy of baked Yb:Y₂O₃ ceramics






Lanthanum

To produce a highly transparent material during sintering several additives are often used, such as ZrO_2 , La_2O_3 , Gd_2O_3 and others. We are using lanthanum oxide.






Selecting the best Lanthanum concentration






Absorption and Luminescence spectra



Lasing experiment






Lasing results

Best slope efficiency was **8%**
(for 4.5% transmission of output mirror)

Lasing power for $R=4.5\%$, W






Cooling

$$\frac{dn}{dT}$$



~10 times

$$\alpha$$




**several
times**

$$\frac{dl}{dT}$$




~ 5 times

$$\alpha_{las}$$





Measurement of Lifetime





Broadening the set of investigated materials

Yb-doped ceramics:

Y_2O_3 - **Japan** (provided by Prof. Kaminsky)
2% Yb

Sc_2O_3 - **Japan** (provided by Prof. Kaminsky)
2% Yb

Lu_2O_3 - **Japan** (provided by Prof. Kaminsky)
2% Yb

Y_2O_3 – **Nizhny Novgorod, Russia**
5% Yb



Broadening the set of investigated materials

Yb-doped crystals:

YAG - **Germany** (provided by Moltech GmbH)

10% Yb

YAG - **St.-Peterburg, Russia**, (Vavilov Institute)

10% Yb

YAG - **Italy**


1% Yb

YAG - **Erevan, Armenia** (Laserayin Tekhnika CSC)

1-20% Yb (5 samples)




Lifetime measurements






Lifetime measurements2







Measurement of Luminiscence





Luminescence spectrum measurements








Luminescence spectrum measurements


Luminescence normalized to room temperature






Luminescence spectrum measurements

Luminescence normalized to room temperature








Emission cross section

Crosssection





Results

- Ceramics manufacturing method was developed in Nizhny Novgorod. Optical quality was demonstrated to be high enough to get 8% of slope efficiency
- Wide set of optical ceramics and crystals was tested and there were measured lifetime and cross section change while cooling down to 80K
- Wide spread in parameters behaviour observed for YAG crystals
- It was measured 3.5 increase in cross section for oxides ceramics and decrease of lifetime from 1.1 ms down to 0.9 ms and it was observed similar behavior for SHS-MS manufactured ceramics
- Measured 3.2 increase of cross section and growth of lifetime from 1.1 ms up to 1.6 ms makes $\text{Yb:Lu}_2\text{O}_3$ ceramics quite promising for diode pumped high energy capacity systems
- Measured luminescence spectrums of ceramics showed about several nm spectrum widths at 80K which makes this ceramics promising for amplification of sub-picosecond pulses.