







Target Fabrication Capabilities


**Presented to
NIF Users Group
February 14, 2012**

Alex Hamza


The target is one of the key elements of a successful experiment



Results!!




Discipline is critical to the success of the effort



We can make the impossible, but it might take a little time

Target Components


- Hohlraums, half hohlraums (vacuum and gas filled)– Gold, Uranium, Pb
- Capsules – CH(Ge), Be(Cu), High density carbon (W), SiO₂, Au/Cu
- Stepped and rippled planar packages – Al, Cu, Foam (Aerogel and Metal), High density carbon, Ta, Fe, LiF
- Cones – Gold
- Shields



“Hohlraums”



Capsules



Rippled HDC



Gold Cone




Unconverted light shield

Target Fabrication Capabilities


- **Micromachining - diamond turning lathes, precision milling, precision grinding, laser machining, polishing, lithography**
- **Physical vapor deposition (ion assisted), chemical vapor deposition (plasma assisted), electro-deposition, atomic layer deposition**
- **Doping, Implantation**
- **Novel Materials – Aerogels, Nanoporous metals**
- **Precision Assembly**
- **Component and Target Metrology**

5 mm




Half hohlraum

Be(Cu) Capsule



2mm

Silicon Cooling Arms and Thermomechanical package




5 mm

General Atomics is an integrated partner in target fabrication




A number of target platforms have been commissioned on NIF


Cryogenic Ignition and Tuning




Radiation Transport




Materials Dynamics and
Equation of State




Hydrodynamics



Discipline is critical to the success of the effort




Materials dynamics experiments will measure the resistance-to-deformation of samples at high pressure



- **Critical target fabrication challenges include:**
 - Low Z graded density structures from 1 to 0.001 g/cc
 - Rippled Ta and V samples with small grain size and appropriate thickness


Silica aerogel “glue” was invented to produce step graded density reservoir




“Negative” digital radiograph of stepped graded density reservoir

Rippled Ta samples were produced by coining so that resistance-to-deformation of wrought materials can be measured

Rippled Ta produced by coining



Coining die



50 and 100 micron period 4 micron peak to valley ripples were successfully transferred to the Ta sample

White light interferometry provides target metrology

Surface Stats:

Ra: 1.22 μm

Rq: 1.36 μm

Rt: 4.56 μm



Measurement Info:

Magnification: 50.22


Measurement Mode: VSI

Sampling: 197.13 nm

Array Size: 2536 X 761




Materials Dynamics



Nuclear physics experiments may require placing isotopes in or near a burning plasma

Fusion Applications Target




- A non-shrinking low-density nanoporous scaffold is being designed
- Casting of the precursor is being studied
- Whether the scaffold can survive hydrogen wetting is also under investigation
- Doping of the scaffold is also being explored

New aerogels are being designed for nuclear physics experiments as a scaffold for dopants



Non-shrinking low-density polymer aerogels

Dicyclopentadiene (DCPD) cross-linked polymer network




DCPD monomer

Ru catalyst
toluene




TEM Image of a
30 mg/cc DCPD aerogel

Carbon nanotube reinforced carbon aerogels



Requires high temperature pyrolysis, but elastic behavior up to very large (~90%) strains





Worsley M.A. *et al.* 2009 *Appl. Phys. Lett.* 94, 073115
Worsley M.A. *et al.* 2009 *J. Mater. Chem.* 19, 3370
Worsley M.A. *et al.* 2008 *Langmuir* 24, 9763

We have developed mechanical robust, ultra-low density polymer and carbon aerogels

Deterministic Layer Formation

Two perpendicular and independently driven rotating frames provide a deterministic, continuous change in orientation relative to the gravity simulating a microgravity environment.



**Projected track of
a point on a
sphere after 150
sec
(10 and 14.14rpm)**


**2 mm diamond
shell with an
~50-micron-
thick layer of a
DCPD polymer
gel**




Uniform and smooth foam coatings can be fabricated

**Capsule coated with a
~40 μm thick uniform
DCPD/NB foam layer**



(50 mg/cc DCPD with 10%
Norbornene, iodine doped
and super-critically dried)



Uniform and smooth foam coatings can be fabricated




Concentricity and inner surface roughness of dried foam shell



The non-concentricity (mode 1) is less than 3 micron, and the high mode surface roughness (> mode 10) is less than 10 nm.


The scaffold has to withstand the capillary pressure of hydrogen wetting

Organic aerogel immersed in liquid hydrogen



Atomic layer deposition is being used for doping of the Nanoporous materials

Atomic layer deposition process




Ruthenium Doped Carbon Aerogel




D₂-fill experiments




Room temp – Iodine-doped 50 mg/cc
DCPD/NB dry foam



D₂ wet foam @
19.5K



Overfill




Aerogel layer defines liquid D₂ layer

Novel materials are frequently needed


**Metal Oxide
Aerogels**




**Single Slot
Target**




**Nanoporous Metals
& Organic Aerogels**



**High-Z Nanoporous
Metals**



A broad range of monolithic aerogel compositions have been synthesized



Monolithic aerogels prepared along with density range in mg/cc


New materials, novel engineering and advanced fabrication techniques are often required

**Copper Foam
(cast, machined, and cut)**




**8-15% relative
density**

**SEM of Copper foam/Al
bond line**





**VISAR signal showing
shock breakout**



Various metrology tools are used to determine target specifications are met (i.e. capsule shape, isolated defects and homogeneity)





Atomic Force Spheremapper





Shape and roughness

Phase Shifting Diffractive Interferometry (PSDI)





Isolated defects & uniformity

Precision Radiograph



Uniformity




Double-sided White-light interferometer is used to scan both sides of a sample simultaneously



The above image represents the dual-roof mirror/right angle mirror design, measuring system objective and reference artifact. Equal length front and rear paths are schematically shown


Measurement of a stepped diamond sample front and rear surfaces using double side interferometer

Stepped Diamond Measurement




3D mapping of ripple and step targets to ~ 1 micron accuracy


3D mapping of millimeter-sized structures with nanometer precision



Two oppositely mounted
“nano-finger” non-contact
sensor heads



Al ripple target




3D mapping of ripple and step targets to ~ 250 nm accuracy

3D Imaging and Quantification

Confocal Micro X-ray Fluorescence

- 3D elemental Imaging
- 3D density measurements
- 30 micron resolution




Micro X-ray Computed Tomography

- non-destructive 3D imaging
- 2 micron resolution


Other imaging techniques available include: scanning electron microscopes, surface scanning laser confocal microscopy.

Shear instability (Kelvin-Helmholtz) targets fielded at Omega with University of Michigan required ripples machined in low density foam


50mg/CC CRF



Plastic w/tracer




1.0 mm



Assembled Physics Package

Materials are chosen to match the physical scaling




Backlit Image of Instability

**Tuning targets:
Keyhole**



2 mm

Tuning Targets: Re-emit




2 mm






High Density Carbon ICF Capsules





2 mm




EOS Step Target Sample



Double shells require precision and novel engineering





Dymanic Hohlraum Target



1.2 mm

Machined capsules with P8 Modulations at different amplitudes






5 um amplitude perturbations

CT scan and image of 10um sinewave capsules for April 2011 ABEX

Capability to fabricate complex diamond targets for HED physics experiments

Ripples & steps




NIF



Energy Balance




NEL Hydro Experiment



1.6 mm

Resistance to deformation
Drive Target






Equation of State Target



5 mm


Materials Dynamics




Atomic-layer-deposition (ALD) is ideally suited to coat ultra-high aspect ratio materials with uniform and conformal films

ALD employs sequential, self-limiting surface reactions to overcome diffusion limitations. Both conformal films (left) and individual nanoparticles (right) can be grown, depending on the surface chemistry



The $\text{Al}(\text{CH}_3)_3/\text{H}_2\text{O}$ process: Growth rate $\sim 0.1 \text{ nm @ } 35\text{-}300^\circ\text{C}$



Overall stoichiometry




Half reactions



Other possible ALD processes:


TiO_2 ($\text{TiCl}_4/\text{H}_2\text{O}$), ZnO ($\text{Zn}(\text{C}_2\text{H}_5)_2/\text{H}_2\text{O}$), W ($\text{WF}_6/\text{B}_2\text{H}_6$).

Radiation Transport Target




5 mm

Cryogenic targets for the ignition campaign




**Capsule centered
in hohlraum with
100 nm formvar
polymer - Target
for OMEGA**




500 μm



Materials Dynamics



Vanadium Ripple Sample



Vanadium Ripple Omega Target